

CONTENTS AT A GLANCE

CONTENTS	4
PART ONE	
ELECTRIC GUITAR BASICS	11
WOOD	14
HARDWARE	20
GUITAR ELECTRONICS	31
TOOLS AND JIGS	56
PART TWO	
DESIGNING YOUR GUITAR	144
MAKING TEMPLATES	160
MAKING THE NECK	
Making the fretboard	172
Making a neck with angled head	190
Making a neck with offset head	236
Making a through-body neck	254
MAKING THE BODY	
Making a solid body	258
Making neck-through body wings	293
Making a semi-solid body	299
Making a semi-acoustic body	312
APPLYING THE FINISH	335
ASSEMBLY	361
SETUP	367
SH!T HAPPENS	374
GUITAR PHOTOS	382



The red “plus” icon indicates essential additional information that can be found on the website *BuildYourGuitar.com*

CONTENTS

PART ONE

ELECTRIC GUITAR BASICS

ANATOMY OF ELECTRIC GUITARS	11
STYLES	11
TONAL RANGE OF GUITARS WITH 24 FRETS	12
ELECTRIC GUITAR SOUND	13
WOOD	
WOOD BASICS	14
WOOD MOISTURE CONTENT	15
RELATIVE HUMIDITY	15
DRYING WOOD	15
BUYING WOOD	16
GUITAR KITS	16
REPLACEMENT NECKS AND BODIES	16
TONEWOOD	16
BUYING WOOD AT THE SAWMILL	16
UNUSUAL SOURCES OF WOOD	17
WOOD FOR AN ELECTRIC GUITAR	17
WOOD FOR THE BODY	17
MAN-MADE BOARDS	17
BODY BLANK CONSTRUCTION METHODS	18
NECK BLANK CONSTRUCTION METHODS	19
WOOD FOR BODY TOPS	20
WOOD FOR THE NECK	20
WOOD FOR THE FRETBOARD	20
HEAD VENEER WOOD	20

HARDWARE

STRINGS	20
TUNERS	20
NUTS	21
GRAPHITE NUTS	21
ROLLER NUTS	21
WEBSTER NUTS	22
LOCKING NUTS	22
ZERO-FRETS	22
MAKING BONE NUT BLANKS	22
BRIDGES	23
BRIDGES FOR HEADLESS GUITARS	24
BRIDGES MOUNTED ON TWO POSTS	24
BIGSBY VIBRATO TAILPIECE	25
TREMOLO BRIDGES	25
STRAT-STYLE TREMOLO	25
FLOYD ROSE TREMOLO	26
TREMOLO STOPS	26
FRETWIRE	26
TRUSS RODS	26
SINGLE-ROD TRUSS-RODS	27
TWIN-ROD TRUSS-RODS	27
COVERS AND PLATES	28
PICKGUARDS	28
SPRING CAVITY COVERS	28
TRUSS ROD NUT COVERS	28
NECK ATTACHMENT HARDWARE	29
SMALL PARTS	29
SCREWS	29
CONTROL CAVITY COVERS	29
TOGGLE SWITCH PLATES	29
JACK PLATES	29
STRING RETAINERS	30
STRAP BUTTONS	30
STRING MOUNTING FERRULES	30

GUITAR ELECTRONICS

CONVERTING STRING MOVEMENT	30
MAGNETIC PICKUPS	31
SINGLE-COIL PICKUPS	31
HUMBUCKERS	31
SPECIAL TYPES OF PICKUPS	32
PIEZO-ELECTRIC PICKUPS	32
PASSIVE CIRCUITS	33
READING CIRCUIT DIAGRAMS	33
OUTPUT JACKS	33
USING THE CONTROLS ON THE AMPLIFIER	34
CONTROLLING THE VOLUME	34
RESISTORS	34
POTENTIOMETERS	34
STEREO POTENTIOMETERS	35
VOLUME CONTROL CIRCUIT	35
SLIDER POTENTIOMETERS	36
POTS WITH INTEGRATED SWITCH	36
CONTROLLING THE SOUND	36
CAPACITORS	36
TONE CONTROL CIRCUIT	37
TREBLE BLEED CIRCUIT	38
CONTROLLING VOLUME AND TONE	38
SWITCHES	38
BASIC PICKUP SWITCHING	40
PICKUP COIL SWITCHING	42
ACTIVE CIRCUITS	42
POWER SUPPLY	42
ACTIVE PICKUPS	43
OPERATIONAL AMPLIFIERS	43
BUFFER CIRCUIT	44
MIXING INDEPENDENT PICKUP SIGNALS	44
STATE VARIABLE FILTER	45
SHIELDING	46
MAKING A SINGLE-COIL PICKUP	46
MAKING A PICKUP WINDER	47
COUNTING THE WINDINGS	48
PREPARING THE BOBBIN	50
MOUNTING THE BOBBIN	50
WINDING THE COIL	50
WIRING THE PICKUP	52
POTTING THE PICKUP	53
VACUUM-ASSISTED POTTING	54
MEASURING PICKUP DATA	55

TOOLS AND JIGS

WORKSHOP	56
WORK TABLE	56
HAND TOOLS	57
MEASURING TOOLS	57
VERNIER SCALE RULER	58
MARKING TOOLS	59
HOLDING AND CLAMPING TOOLS	60
VACUUM HOLDING AND CLAMPING	66
MANUAL VACUUM PUMPS	67
ELECTRICAL VACUUM PUMPS	67
VENTURI PUMP	68
ADVANTAGES OF VACUUM CLAMPING	69
VACUUM BAG CLAMPING	69
ATTACHING TEMPLATES USING VACUUM	70
VACUUM WORKHOLDING	71
ADHESIVES FOR TEMPORARY FIXING OF PARTS	71
CUTTING TOOLS	71
SHARPENING	75
ELECTRONICS TOOLS	78
POWER TOOLS	80
BANDSAW	80
JIGSAW	81
MOUNTING THE JIGSAW UPSIDE DOWN	81
TABLE SAW	81
CUTTING FRETSLOTS ON THE TABLE SAW	81
TABLE SAW TAPERING JIG	82
ROUTER	83
SETTING THE CUTTING SPEED	85
SETTING THE CUTTING DEPTH	85
ROUTER BITS	86
FOUR ESSENTIAL ROUTER BITS	88
USING BALL-BEARING-GUIDED BITS	89
USING GUIDE BUSHINGS	89
USING AN EDGE GUIDE	90
CUTTING THE CAVITY AND THE INLAY	90
USING ONE TEMPLATE	90
SMALL-RADIUS-CIRCLE-CUTTING	90
SELF-CENTERING SUBBASES	91
OFFSET ROUTER SUBBASES	91
LARGE-RADIUS-CIRCLE-CUTTING JIG	92
TABLE ROUTER	92
NO-VOLT-RELEASE (NVR) SWITCH	94
TABLE ROUTER SAFETY	94
JOINTING ON THE TABLE ROUTER	96
INCRA MAGNALOCK GUIDE BUSHING RING	97
THE PROTUS KURVENLINFIX FLEXIBLE GUIDE	98
CNC ROUTER	98
PIN ROUTER	99
SIMPLE PIN ROUTER	100

INVERTED PIN ROUTER	100	PREVAL SPRAYER	133
SPINDLE SANDER	100	COMPRESSED-AIR SPRAY GUN	134
OSCILLATING SPINDLE SANDER	101	ROUND-PATTERN SPRAY GUNS	134
INSTALLING AND USING A GUIDE RING	101	CHOOSING THE RIGHT SPRAY GUN SIZE	135
JOINTING WITH A SPINDLE SANDER	102	WET-FILM THICKNESS GAUGE	136
THICKNESSING WITH A SPINDLE SANDER	102	SETTING THE INPUT PRESSURE	136
DRILL STANDS	103	SETTING THE SPRAY PATTERN	137
SMALL SANDING MACHINES	103	COMPRESSED-AIR SUPPLY AND FITTINGS	138
		SPRAYING TECHNIQUE	139
GITARMAKING TOOLS	104	VISCOSITY CUP	139
		SPRAYING TEST PANELS	140
GUITAR MAKING JIGS	109	CLEANING A SPRAY GUN	140
JIG FOR DRILLING TRUSS ROD ACCESS HOLES	109	DISPOSABLE PAINT CUPS	142
15-DEGREE SAW GUIDE	110	AIRBRUSH	143
GUIDE FOR CUTTING CURVED TRUSS ROD CHANNELS	111	SANDING AND POLISHING TOOLS	143
NECK POCKET JIG	111		
VERTICAL CLAMPING ATTACHMENT	113		
FRETBOARD-TAPERING JIG	113		
OUTPUT JACK HOLE CUTTING JIG	113		
EXTRA-LONG ROUTER SUBBASE	114		
SURFACING JIG	114		
SURFACE-RADIUSING JIG	115		
FLOATING ROUTER SUBBASE	116		
ANGLED-SURFACE PLANING JIG	116		
BINDING-CHANNEL CUTTING ATTACHMENT	117		
FRETBOARD RADIUS CUTTING JIG	118		
MAKING THE CURVED ROUTER SUBBASE	118		
MAKING THE TABLE	119		
FRET-SLOTTING GUIDE	120		
MICROPROCESSOR-ASSISTED FRET-SLOTTING GUIDE	121		
CALIBRATING THE JIG	124		
MAKING A NECK REST BAG	125		
BEZIER CURVE TOOLS	126		
ADHESIVES	126		
FINISHING MATERIALS AND EQUIPMENT	128		
STAINS	128		
DYES	128		
OIL FINISHES	128		
VARNISH	128		
WAX FINISHES	128		
SHELLAC	128		
PAINT	129		
NITROCELLULOSE-BASED FINISHES	129		
WATER-BASED FINISHES.	129		
2K FINISHES	129		
RESPIRATOR MASK AND GLOVES	130		
SPRAY BOOTH	130		
BODY SUPPORT FOR SMALL SPRAY BOOTHS	130		
NECK SUPPORT FOR SMALL SPRAY BOOTHS	131		
STEW MAC'S FREEHAND HOLDER	132		
AEROSOL SPRAY CANS	132		
PREPARING THE CAN	133		
CLEANING A SPRAY CAN	133		

PART TWO

DESIGNING YOUR GUITAR

CALCULATING FRET POSITIONS	144
CHOOSING A SCALE LENGTH	144
BASIC LAYOUT OF A GUITAR	145
BASIC LAYOUT OF A BASS GUITAR	146
MULTIPLE-SCALE FRETBOARD	148
LAYING OUT THE HEAD	149
TYPICAL TUNER SHAFT DIAMETERS	149
MINIMUM TUNER SPACING	149
TUNER MOUNTING HOLES DISTANCE FROM HEAD EDGE	149
HEAD WITH ALL TUNERS FITTED ON ONE SIDE	150
HEAD WITH TUNERS FITTED ON BOTH SIDES	151
DRAWING THE BODY SHAPE	153
COPYING EXISTING DESIGNS	154
REFINING THE LAYOUT	155
MARKING THE PICKUP POSITION(S)	155
CHOOSING A FRETBOARD RADIUS	156
DRAWING THE NECK PROFILE	156
CHOOSING THE TRUSS ROD ACCESS SIDE	157
DRAWING CROSS-SECTION VIEWS	157
CHOOSING AN ARTWORK	157
FINDING A CONTRASTING COLOR	157
WRITING A SPECIFICATION DATA SHEET	157
EXAMPLES OF GUITAR DESIGN	158

MAKING TEMPLATES	160
TEMPLATE MATERIAL	160
PRINTING YOUR DESIGN	160
TRANSFERING YOUR DESIGN TO THE TEMPLATE	161
USING CARBON COPY PAPER	161
TONER TRANSFER	161
GLUING THE PRINTOUT ON THE TEMPLATE	162
MAKING A FRETBOARD TEMPLATE	163
MAKING A HEAD TEMPLATE	164
MAKING A BODY TEMPLATE	166
MAKING NECK POCKET TEMPLATES	168
MAKING REAL-SIZE NECK POCKET TEMPLATES	168
MAKING OFFSET NECK POCKET TEMPLATES	168
MAKING PICKUP TEMPLATES	168
TREMOLO TEMPLATE OUTLINES	169
MAKING A CONTROL CAVITY TEMPLATE	170
MAKING A HOLLOWING-OUT TEMPLATE	170
MAKING AN F-HOLE TEMPLATE	170
COPYING READY-MADE TEMPLATES	171
CONVERTING REAL-SIZE TEMPLATES	171
ATTACHING TEMPLATES	171

MAKING THE NECK

MAKING THE FRETBOARD	172
FLATTENING THE GLUING SURFACE	172
THICKNESSING THE FRETBOARD BLANK	172
TRUEING ONE EDGE OF THE BLANK	172
MARKING THE CENTERLINE ON THE FACES	172
CUTTING FRET SLOTS ON THE TABLE SAW	172
CUTTING THE FRETBOARD RADIUS	173
USING A RADIUS-SANDING BLOCK	173
USING A FRETBOARD RADIUSING JIG	174
MARKING THE FRET SLOT POSITIONS	176
A CLOSER LOOK AT THE ZERO-FRET SLOT	176
CUTTING THE FRET SLOTS	177
USING FRET SCALE TEMPLATES	177
USING THE FRET-SLOT-CUTTING JIG	178
DRAWING THE CENTERLINE	179
CUTTING THE FRETBOARD TO LENGTH	179
MARKING THE FRETBOARD WIDTH	180
ROUGH-CUTTING THE FRETBOARD TAPER	180
TAPERING THE FRETBOARD	181
BINDING THE FRETBOARD	182
INSTALLING FRETBOARD DOTS	182
INSTALLING SIDE DOTS	183
INSTALLING BLOCK INLAYS	184
INSTALLING A 12TH-FRET INLAY	185
DRAGON INLAY	186
ABS-FILLED INLAY	189
MAKING A NECK WITH ANGLED HEAD	190
THICKNESSING THE NECK BLANK	190
JOINTING ONE EDGE	190
CUTTING OFF THE HEAD PART	191
THICKNESSING THE HEAD PART	192
SMOOTHING THE CUT	193
GLUING ON THE HEAD PIECE	194
GLUING ON EARS	197
FINAL SMOOTHING OF THE HEAD SURFACE	197
MARKING THE NECK CENTERLINE	198
INSTALLING A STRAIGHT TRUSS ROD	198
CUTTING THE TRUSS ROD CHANNEL	198
FITTING THE TRUSS ROD NUT	200
INSTALLING A CURVED TRUSS ROD	201
CUTTING THE TRUSS ROD CHANNEL	201
MAKING THE TRUSS ROD COVER STRIP	203
GLUING IN THE TRUSS ROD COVER STRIP	203
PREPARING THE HEAD VENEER	204
THICKNESSING THE HEAD VENEER	204
INLAYING A HEAD LOGO	204
PAINT-FILLED LOGO	205
OPTIONAL: CUTTING THE TRUSS ROD ACCESS HOLE	206
GLUING ON THE HEAD VENEER	206
CUTTING THE FRONT EDGE OF THE HEAD VENEER	207
DRILLING THE TRUSS ROD NUT ACCESS HOLE	207
ADDING A HEEL TO A GLUED-IN NECK	209
GLUING ON A HEEL	209
CUTTING THE NECK TENON	209
SHORTENING THE NECK TENON	211
GLUING ON THE FRETBOARD	212
CLEANING THE FRETBOARD EDGES	214
ROUGH-CUTTING THE HEAD SHAPE	214
ROUGH-CUTTING THE NECK SHAPE	215
FLUSH-TRIMMING THE HEAD	215
FLUSH-TRIMMING THE TREBLE SIDE OF THE NECK	217
FLUSH-TRIMMING THE BASS SIDE OF THE NECK	217
FLUSH-TRIMMING THE GAP AREA	218
BINDING THE HEAD	219
CUTTING THE BINDING RABBET	219
FITTING AND GLUING ON ABS BINDING	220
DRILLING THE TUNER HOLES	221
INSTALLING THE FRETS	222
SANDING THE FRETBOARD	222
DEEPENING THE SLOTS	222
CLEANING THE FRET SLOTS	222
CLEANING THE FRETWIRE	222
BENDING THE FRETWIRE	223
CUTTING OFF PIECES OF FRETWIRE	223
CUTTING FRETWIRE FOR BOUND FRETBOARDS	223
HAMMERING THE FRETS IN	224
PRESSING THE FRETS IN	225
CUTTING THE FRET ENDS FLUSH	226
SECURING THE FRET ENDS	226
FILING THE FRET ENDS FLUSH	226
BEVELING THE FRET ENDS	226
DRESSING THE FRET ENDS	227
LEVELING THE FRETS	227

PRE-SHAPING THE BACK OF THE NECK	228	MAKING A THROUGH-BODY NECK	254
FINAL-SHAPING THE NECK	230	THICKNESSING THE NECK BLANK	254
SHAPING THE NECK-TO-HEEL TRANSITION	232	GLUING UP THE BODY SECTION	254
SHAPING THE NECK-TO-HEAD TRANSITION	233	THICKNESSING THE BODY SECTION	254
STEPLESS NECK-TO-HEAD-TRANSITION VARIANT	234	CUTTING THE TRUSS ROD CHANNEL	254
REFINING THE NECK	234	INSERTING THE TRUSS ROD	254
		TAPERING THE SIDES OF THE NECK	255
MAKING A NECK WITH OFFSET HEAD	236	GLUING ON THE FRETBOARD	255
THICKNESSING THE NECK BLANK	236	FLUSH-CUTTING THE FRETBOARD	255
JOINTING ONE EDGE	236	CUTTING A STEP AFTER THE FRETBOARD END	255
DRAWING THE NECK CENTERLINE	236	PRE-SHAPING THE BACK OF THE NECK	256
DRAWING THE HEAD AND NECK OUTLINE	236	SANDING THE HEEL CURVE	257
ROUGH-CUTTING THE HEAD SHAPE	237	INSTALLING THE FRETS	257
FLUSH-CUTTING THE HEAD	237	SHAPING THE NECK	257
DRILLING THE TUNER HOLES	238		
OFFSETTING THE HEAD	239		
MAKING A NECK WITH GLUED-ON FRETBOARD	240		
CUTTING THE TRUSS ROD CHANNEL	240		
BODY-END ACCESS TO THE TRUSS ROD NUT	240	MAKING A SOLID BODY	258
HEAD-END ACCESS TO THE TRUSS ROD NUT	240	JOINING THE BLANKS	258
GLUING ON THE FRETBOARD	240	GLUING UP THE BODY	258
CUTTING THE NECK SIDES FLUSH	240	THICKNESSING THE BODY BLANK	269
INSTALLING THE FRETS	240	CUTTING A CYLINDER-SHAPED TOP	260
MAKING A ONE-PIECE NECK WITH OFFSET HEAD	241	GLUING ON AN EXTRA TOP	260
CUTTING THE TRUSS ROD CHANNEL	241	TRANSFERRING THE BODY OUTLINE	262
DRILLING A TRUSS ROD NUT ACCESS HOLE	242	ROUGH-CUTTING THE BODY SHAPE	263
INSERTING THE TRUSS ROD	242	FINE-SHAPING THE BODY SIDES	264
MAKING THE FILLER AND COVER STRIP	243	USING A SANDING DRUM WITH GUIDE WHEEL	264
GLUING IN THE FILLER AND COVER STRIP	243	USING A LONG TRIM CUTTER	264
ROUGH-CUTTING ONE SIDE OF THE NECK	243	USING A SPINDLE SANDER WITH GUIDE RING	265
MARKING THE FRET SLOTS	244	TRANSFERING THE NECK CENTERLINE	266
CUTTING THE FRET SLOTS	244	CUTTING A "GERMAN CARVE"	266
CUTTING THE SIDES OF THE NECK FLUSH	244	ROUNDING OVER THE TOP AND BACK EDGES	268
SANDING THE FRETBOARD RADIUS	245	CUTTING THE NECK POCKET	269
DEEPENING THE FRET SLOTS	246	USING REAL-SIZE NECK POCKET TEMPLATES	269
INSTALLING THE FRETBOARD DOTS	246	USING A GUIDE BUSHING	270
SANDING THE FRETBOARD SURFACE	247	USING A NECK POCKET JIG	271
CLEANING THE SLOTS	247	FITTING THE NECK	275
CLEANING THE FRETWIRE	247	INSTALLING THE NECK	276
BENDING THE FRETWIRE	247	INSTALLING NECK MOUNTING FERRULES	277
PREPARING THE FRETWIRE PIECES	247	BOLTING ON A NECK WITH A SHORT HEEL	278
HAMMERING THE FRETS IN	247	INSTALLING A FLAT-TOP BRIDGE	278
CUTTING THE FRET ENDS FLUSH	248	INSTALLING A BRIDGE ON POSTS	279
BEVELING THE FRET ENDS	248	INSTALLING A SEPERATE STRING HOLDER	280
DRESSING THE FRET ENDS	248	MOUNTING THE STRINGS THROUGH THE BODY	280
LEVELLING THE FRETS	249	CUTTING <i>STRAT</i> -STYLE TREMOLO CAVITIES	282
THICKNESSING THE NECK	249	CUTTING <i>FLOYD ROSE</i> TREMOLO CAVITIES	284
PRE-SHAPING THE BACK OF THE NECK	250	RECESSING A <i>FLOYD ROSE</i> TREMOLO	285
FINAL SHAPING THE NECK	250	CUTTING PICKUP CAVITIES	286
SHAPING THE NECK-TO-HEEL TRANSITION	251	CUTTING HUMBUCKER CAVITIES	286
SHAPING THE NECK-TO-HEAD TRANSITION	252	CUTTING CONTROL CAVITIES	287
FITTING THE NUT	253	CUTTING THIN MOUNTING AREAS	288
		MIND A DOMED TOP	288
		CUTTING A <i>NEUTRIK</i> JACK MOUNTING HOLE	289
		DRILLING THE WIRE CHANNELS	290
		CUTTING A CYLINDRICAL TOP	291
		CUTTING CONTROL KNOB RECESSES	292

MAKING THE BODY

CUTTING A CYLINDRICAL BACK	292	INSTALLING HARDWOOD INSERTS	313
		SHAPING THE SUSTAIN BLOCK ENDS	313
MAKING NECK-THROUGH BODY WINGS	293	CUTTING AN OPENING	314
GLUING UP THE BODY BLANK	293	MAKING THE WORK BOARD	314
THICKNESSING THE BODY BLANK	294	MAKING THE BENDING FORM	315
JOINTING THE SIDES OF THE BODY WINGS	294	MAKING THE MOLD	316
SHAPING THE CUTAWAYS	294	BENDING THE SIDES	316
CHAMFERING THE EDGES OF THE CUTAWAYS	294	GLUING UP THE SIDES	318
GLUING ON THE BODY WINGS	294	MAKING A KERFED LINING	320
CUTTING THE BODY SHAPE	295	GLUING ON THE LINING	321
CHAMFERING THE REMAINING EDGES	296	LEVELING THE LINING	321
CUTTING THE PICKUP CAVITY	296	GLUING THE SIDES TO THE SUSTAIN BLOCK	321
CUTTING THE CONTROL CAVITY	297	GLUING SUSTAIN BLOCK AND SIDES TO THE BACK	322
CUTTING THE JACK HOLE	297	CUTTING THE BACK FLUSH	323
DRILLING THE WIRE CHANNEL	297	GLUING ON THE TOP	324
PATCHING HOLES	298	CUTTING THE TOP FLUSH	325
FITTING THE HEADPIECE	298	INLAYING THE END GRAFT	325
		CUTTING THE BINDING CHANNEL	326
		GLUING ON THE BINDING	327
MAKING A SEMI-SOLID BODY	299	SCRAPING THE BINDING FLUSH	327
PREPARING THE BODY BLANK	299	LEVELING THE HEEL CONTACT SURFACE	327
THICKNESSING THE TOP HALVES	299	DETERMINING THE NECK ANGLE	328
JOINTING THE TOP HALVES	299	CUTTING THE NECK POCKET	329
GLUING UP THE TOP	299	SQUARING THE NECK POCKET CORNERS	329
ROUGH-CUTTING THE TOP AND THE BODY SHAPE	300	BOLTING ON THE NECK	330
LEVELING THE GLUING SURFACE OF THE TOP	300	GLUING ON THE HEEL	331
HOLLOWING OUT THE BODY	300	GLUING ON THE HEEL CAP	332
CUTTING A WIRE CHANNEL	301	SHAPING THE HEEL	332
GLUING ON THE TOP	301	CUTTING THE F-HOLES	333
FLUSH-CUTTING THE SIDES	301	CUTTING THE PICKUP CAVITY	333
CUTTING F-HOLES	301	DRILLING THE ELECTRONICS ENTRY HOLE	333
DRILLING THE SWITCH HOLE	302	INSTALLING THE BRIDGE	334
CUTTING THE CONTROL CAVITY	302	CUTTING THE JACK HOLE	334
CUTTING A BATTERY BOX CAVITY	302		
CUTTING THE CONTROL CAVITY COVER RECESS	303		
CUTTING THE SWITCH HOLE COVER RECESS	303		
MAKING A CURVED TOP	303		
UNDERSTANDING AND GENERATING ISOHYPSES	303		
TRANSFERING THE ISOHYPSES	304		
ROUGH-CUTTING THE TOP	304	APPLYING THE FINISH	
SMOOTHING THE TOP	305		
CUTTING THE BINDING CHANNEL	306	PREPARING FOR THE FINISHING	335
GLUING ON THE BINDING	306	STEAMING OUT DENTS	335
ROUNDING OVER THE BACK EDGE	307	FILLING IMPERFECTIONS WITH PUTTY	335
CUTTING THE NECK TENON POCKET	307	PORE-FILLING	335
FITTING THE HEEL	307	FINE-SANDING	336
GLUING ON A HEEL CAP	307	HEAD LOGO	337
GLUING IN THE NECK	309	APPLYING A DECAL	337
CUTTING THE PICKUP CAVITIES	309	HAND-DRAWN HEAD LOGO	337
INSTALLING A FLOATING BRIDGE	310	APPLYING THREE-DIMENSIONAL LOGOS	337
DRILLING THE JACK HOLE	311		
		APPLYING A PASTE WAX FINISH	337
MAKING A SEMI-ACOUSTIC BODY	312	APPLYING AN OIL FINISH	338
MAKING THE SUSTAIN BLOCK	312		
MAKING THE SUSTAIN BLOCK TEMPLATE	312	FRENCH POLISHING	339
SHAPING THE SUSTAIN BLOCK LAYERS	312	APPLYING A SEALER COAT	339
GLUING UP THE SUSTAIN BLOCK	313	FILLING THE PORES	340
SANDING THE SUSTAIN BLOCK	313	FRENCH POLISHING	341

APPLYING A SPRAY FINISH	343
TAPING OFF THE FRETBOARD	343
APPLYING A TRANSLUCENT COLOR COAT	343
APPLYING OPAQUE COLOR COATS	343
PRIMER COAT	344
APPLYING THE BASE COAT	344
LEVELING THE BASE COAT	345
MIXING COLORS	346
APPLYING THE COLOR COAT	346
SPRAYING A GUITAR WITH ATTACHED NECK	347
SCRAPING A BINDING CLEAN	348
EXAMPLE ARTWORK	348
TIGER STRIPES	348
BLACK AND WHITE ARTWORK	349
FLAME DESIGN	350
FLAME VARIANT	352
PINUP GIRL	354

APPLYING A CLEAR COAT	356
CLEAR-COATING THE BODY	356
CLEAR-COATING A GUITAR WITH ATTACHED NECK	357
LET THE CLEAR COAT CURE	357
CLEAR COATING SCHEDULE	358

FINESSING THE FINISH	358
LEVEL-SANDING	358
WET SANDING	358
COMPOUNDING	359

POLISHING	360
------------------	------------

ASSEMBLY

DATE AND SIGN YOUR WORK	361
FITTING THE TUNERS	361
FITTING THE NUT	362
GROUNDING THE BRIDGE	363
APPLYING SHIELDING PAINT	363
FITTING PICKUP MOUNTING RINGS	364
FITTING THE CONTROLS	364
WIRING THE ELECTRONICS	364
WIRING A SEMI-ACOUSTIC BODY	366

SETUP

STRINGING THE GUITAR	367
DISTRIBUTING THE STRINGS ON THE NUT	368
DISTRIBUTING GUITAR STRINGS	368
DISTRIBUTING BASS GUITAR STRINGS	368
CUTTING SHALLOW NUT SLOTS	368
TUNING THE GUITAR	368
TUNING BY EAR	368
FINE-TUNING BY EAR	369
SETTING THE NECK RELIEF	369
SETTING THE STRING HEIGHT AT THE NUT	370
SETTING THE STRING HEIGHT AT THE BRIDGE	371
CHECKING FOR UNWANTED NOISES	372
SETTING THE INTONATION	372
ADJUSTING THE PICKUP HEIGHT	373
YOUR SELF-MADE GUITAR	374
ABOUT FLAWS AND IMPERFECTIONS	374

SH!T HAPPENS

HOW <i>BORIS</i> WAS BORN	375
PATCHING A FLAW IN THE HEEL	375
PATCHING A STRAY CUT IN A NECK POCKET	376
PATCHING A CAVITY	376
PATCHING <i>PAULINE'S</i> SWITCH HOLE	377
<i>DRAKE</i> HAS A SCAR ON ITS NECK	377
I MADE A TOILET SEAT	379
WHEN FINISHING GOES WRONG	379
REPAIRING A RUB-THROUGH	381
MAKING MESS	381
GUITAR PHOTOS	382